

MANUAL EXTENDER



18" rise

- Raises stream to prevent damage to apparatus equipment
- More ergonomic operating position

Monitor operates in raised or lowered position

- Full 360° rotation in either position

Automatically locks in up/down position

- Cannot be accidentally unlocked
- Prevents unintended extension under pressure
- Prevents unintended collapse when extended

Built-in sensor for connection to cab indicator light

- Notifies personnel when Extender is NOT stowed and locked

3" waterway

- Capable of 1250 gpm flow

MOUNTING OPTIONS

- Dual bracket
- Plate and saddle bracket

INLET OPTIONS

- 3" Victaulic
- 3" NPT
- 3" NPT with 150# Flange*

OUTLET OPTIONS

- 3" NPT
- 3" NPT with 150# Flange*

*Flange sold separately



**EASY-OP LATCH DESIGN
FOR SAFE AND SIMPLE
DEPLOYMENT**

MANUAL EXTENDER

ORDERING GUIDE

1

Select one of the Extender packages below

08599001

Manual Extender
3" MNPT inlet
3" MNPT outlet
Dual saddle brackets

08599011

Manual Extender
3" Victaulic inlet
3" MNPT outlet
Dual saddle brackets



DUAL SADDLE BRACKET

08599012

Manual Extender
3" MNPT inlet
3" MNPT outlet
Plate and saddle bracket

08599013

Manual Extender
3" Victaulic inlet
3" MNPT outlet
Plate and saddle bracket



PLATE AND SADDLE BRACKET

2

Select monitor option (sold separately)

Recommended

- Stinger 2.0 (deck mount)
- Stinger 2.0 (portable)

See Stinger 2.0 selector guide for mounting connection options



STINGER 2.0

3

Select nozzle option (sold separately)

- SM-1000 2.5" Automatic nozzle
- SM-1250 2.5" Automatic nozzle
- 282A Stream Shaper (no charge when purchased with Stinger 2.0)
- Quad Stacked Tips (no charge when purchased with Stinger 2.0)



SM SERIES
AUTOMATIC NOZZLE

This is intended as a guide only. For all options and configurations, please contact your Elkhart Brass Regional Sales Manager or Customer Service.